


Fire & Security Solutions

Changing the Time & Date



Purpose

The Time/Date option allows the user to modify both the time (hours/ minutes) and the date (day/month/year).

Selecting Time/Date

Enter the QUICK MENU (7) or FULL MENU (41) followed by the ent key. Once the Time/Date option has been selected, the time or date can be selected by pressing the A> or B> key.

Changing Time.

To change the time press the A> key. The display prompts for a New Time in hours and minutes (HH:MM). When the new time is entered, the display immediately returns to the time or date selection screen. The system does not accept invalid times (greater than 23 hours, greater than 59 minutes). Pressing the esc key aborts the entry.

Changing Date.

To change the date press the < B The display prompts for a New Date in days, months and years (DD/MM/YY). When the new date is entered, the display momentarily shows the day of the week, before returning to the time or date selection screen. The system does not accept invalid dates (e.g. 32/13/99). Pressing the esc key aborts the entry.

Advance and Retard.

It is possible to advance and retard the time to compensate for any variations in clock speed. Press the # key when in the time/date mode to select the clock speed adjustment. The range is 0 to 120 seconds per week. Pressing the * key will retard the time