


# Fire & Security Solutions

## **Display Log**



#### Purpose.

The Display Log option provides the user with a means of viewing the system history. Events are recorded in detail and stored in the memory.

### Selecting Display Log.

Enter the QUICK MENU (4), or Full Menu (22) followed by the ent key. Details of the most recent event to be logged are displayed.

**Events**. The events available for display include details of setting, unsetting and alarms. Each event is time and date stamped.

#### Selecting a Date.

Hold down one of the view keys, the dates held in the log are rapidly stepped through. The A> key moves forward through the dates and the <B moves backwards. Stopping at the required date reveals the first event for that date.

### Viewing Each Event.

The entire events of any one date can be viewed by progressively stepping through the events using the A> and <B view keys. \* If the user has group choice enabled, the groups will display. Events for each group can be displayed by entering the group number.

#### Additional Information.

The # key can be used to reveal additional information on some types of events. This information is displayed on the bottom line. The information includes details such as zone descriptors, user types and which keypad was used.