

Resetting the System

CALL MANAGER RESET REQUIRED 4 ALARMS [<] [>] to View CALL ALARM CO. QUOTE CODE XXXXX	Resetting after and Alarm activation. Should the alarm activate during the SET condition, a code or fob will be used to silence the alarm on entry. The alarm keypad will display “Call Manager Reset Required”. Enter the manager code or preset a valid fob and then press ent. Use the <A Key to view each of the alarms highlighted on the keypad, each alarm activation will need to be investigated for a valid cause before a reset can be carried out. Once all the alarms have been viewed, we need to ensure the keypad comes up with “end” Manager Reset. Entering a manager type PIN followed by ent, resets the system following an alarm activation. Engineer Reset. Certain types of alarm require an engineer to visit the site and, after investigation, reset the system. In such cases, the system cannot be reset until the engineer reset has been carried out <u>Remote Reset</u> The Keypad Displays Call Alarm Company, Quote (e.g 12345), Phone (24hr) Tel No, Quote BLK No, Give the operator the 5 Digit Reset No, in exchange for a 5 Digit Reset No, Enter this in the Keypad, The System is now fully Reset. The Keypad Displays Black Box Alarms.
---	--